
Schematic diagram



Key numbers

put it into the switch cap. Note: read the instructions on the back and install first. Cut out the icon with scissors and

Black	0	Brown	ш	Yellow	4	violet	7	MODE
A	•	Red	2	Green	5	Gray	00	\$ *
В	11	Orange	w	Blue	6	White	9	1
0	+	None D	ı	511	×	Gold 📭	-1-	ON AC

Black	0	Brown	Н	Yellow	4	violet	7	MODE
A	•	Red	2	Green	5	Gray	00	*
В		Orange	ω	Blue	6	White	9	1
0	+	None D	1	Silver E	×	Gold F	- -	ON

Key description

ı		
MODE	Mode: Press this button to switch between functions.	
	Square root and selection key:	

* When using the calculator, press this button to switch to the square roof function.
 When calculating current, the voltage and current are inputted through this key.
 When calculating the resistance of a color ring, this key is used to salect the functions of a 5-ring or 4-ring resistor When converting decimal and hexadecimal numbers, use this button to switch the

1 incorrect number. Switch/clear key Backspace key: in calculator mode, clear the input of a single

0 Press this to turn on the power. The power will automatically turn off after 30 seconds of inactivity.
 Clear all displayed results or input content. text below. The keys have numbers or symbols on top and colors and

The bottom right corner of the keys has uppercase red letters A, B, C, D, E, F.
In the decimal conversion function, press 0-9A-F to enter a value.

For color ring resistance, the colors are located below the keys.

[roubleshooting

. If the diy kit does not work properly after installation:

check if the battery voltage is 3V tion, check if the solder joints are qualified and have good contact, and Check if the components are installed in the correct position and direc

solder can easily wrap around the pins and solder pads. soldering usually takes 1-2 seconds for one joint, with strong fluidity. The the pins and solder pads. It may take 4-5 seconds to solder one joint. Normal or poor quality solder, which makes it difficult for the solder to wrap around often caused by improper solder selection, using high melting point solder appear to be properly soldered, in reality it may have poor contact. This is Solder joints are crucial, especially for virtual ones. Although it may

Display brightness is very low:

a voltage of about 3V Check if R3 and R4 resistors are installed correctly. Check if the battery has

Operation instruction

Use 2 CR032 button batteries for power supply; press the ON button to turn on the power; the device will automatically turn off after 30 seconds of inactivity. batteries: Due to the small battery capacity, frequent use or long standby time of the calculator may result in insufficient power

Function 1. Decimal arithmetic operation, with decimal point and negative number operation

or example, calculate 5*6=30

Operation method: Turn on the power with the [ON] button, press [5], press [4] press [6], press [-3]. The result is [30]. Press [AC] to clear.

For example, calculate -8+2=-6

Operation method: turn on the power with the 【ON】 button. Press【-】, 【8】, 【+】, [2], [=]. The result is -6. Press [AC] to clear

unction 2: Calculation of 4-ring or 5-ring resistance. Enter the color rings in order to obtain the resistance value

For example, the 5-ring resistance with yellow, purple, black, brown, brown has a resistance value of 4700 Ω

5-ring resistance. Press [Yellow] , [Violet] , [Black] , [Brown] . Operation method: Turn on the power with the [ON] button, press [MODE] to switch to the Color Ring R C 5 interface to calculate the [Brown] to obtain the resistance value R=4700Ω with a 1% error

Press [AC] to clear.

For example, the 4-ring resistance with green, red, yellow, and gold has a resistance value of $520\mathrm{K}\Omega$

Operation method: In the Color Ring R C 5 interface, press and hold the [🌎] key to switch to the Color Ring R C 4 interface to calculate


Press [AC] to clear. Press [MODE] to select other functions. Press 【Green】,【Red】,【Yellow】,【Gold】to obtain the resistance value R=520K Ω with a 5% error margin

If "error" appears in the result, it indicates an operational error.

Function 3. When the supply voltage and working voltage and current of the LED are known, the resistor value required to connect in series with the LED can be obtained.

Formula:
$$R = \frac{U}{1} = \frac{Vi-Vd}{1}$$

Vd is the working voltage of the LED; Vi is the supply voltage of the LED; limiting resistor; R is the resistance value of the current I is the working current of the LED;



For example, when the supply voltage (Vi) of the LED is 5V, the working voltage (Vd) of the LED is 3V, and the voltage difference (Vi-Vd) across the resistor is 2V, the working current (i) of the LED is 10mA. What is the value of the series resistor (R)?

Operation method: Turn on the power with the $\{ON\}$ button, press $\{MODE\}$ to switch to the $\{Rled\ VI-Vd=VI=mAR=R\}$ interface, press [2] (Vi-Vd=2V), press [I to switch to current input, press [1] [0] (LED working current, 10mA)

Press $\{=\}$.The value of the series resistor R is 200 Ω .

Press [AC] to clear. Press [MODE] to select other functions

Function 4: Conversion between decimal and hexadecimal numbers: conversion between hexadecimal and decimal numbers.

imal number to a hexadecimal number. Enter the decimal number to automatically calculate the hexadecimal number Operation method: turn on the power with the [ON] button. Press [MODE] to switch to the 10HEX-16HEX interface to convert the dec

Press [AC] to clear.

Press [🏶] to switch to the 16HEX-10HEX interface to convert the hexadecimal number to a decimal number. Enter the hexadecimal number to automatically calculate the decimal number

Press [AC] to clear. Press [MODE] to select other functions

Function 5: Square roo

For example, $\sqrt{4} = 2$

press [=] . The result is [2] Operation method: turn on the power with the [ON] button, in the calculator mode, press $[\Phi]$, $\sqrt{0}$ will appear. Press [4], then