

Auto Bilge Pump Installation Instructions

WARNING:

- To prevent injury, always disconnect the power source when installing or servicing any electrical product.
- DO NOT use pump to remove gasoline oil or other flammable liquids.
- Always use the fuse amperage rating specified for your pump model.
- Failure to do so could result in serious personal injury or fire hazards.

OPTIONAL MATERIALS

- 1/2"-thick marine plywood block (slightly larger than pump base)
- Waterproof adhesive (epoxy, silicone adhesive, or fiberglass resin) to mount block.
- 18-gauge wire (brown brown white and black).