



Multi-function wireless Bluetooth audio installation manual

Bluetooth reception, hands-free calls, can be forwarded back, card MP3 player, AUX function, radio function




(installation)


1




2



3




4



5

Use two 2 * 8mm screws


Yellow wire soldering radio antenna port



The left side of the welding positive red line

The right side of the welding negative black line

6



Red, black wire welding in the back of the terminal, between the solder joints must not be shorted


7 maximum terminal welding

The longest pin then red line, yellow and black line

The longest pin is connected to the antenna terminal yellow line


8

The middle of the jack can not be lost



Welding black line

Take the black line



Take the red line

Acoustic enclosure assembly diagram

9

Inside the battery compartment line to red socket

Step 1: use two 2 * 8 the screw connection of the front panel and bottom plate

Acoustic enclosure assembly diagram

10


Step 2: plug two horn line into two white inside the socket
The two side panels with 2 * 8 screws on the front panel that is

11

The red and the black welding to the power card

Plug the audio input line into decoding on a board

The yellow wire welding to insert in the middle of the feet



The third step: after the board with 2 * 8 screws to the side panel and floor

12

The first step: the horn first pack from the front of the circle



Step 2: the horn of circles, the black net loaded on the horn again can

Hands down the black net week into his tight black net, that is no longer black network become warped up affect beautiful

13



Note: the network installation must compress strong one with a decorator, otherwise sound can produce resonance noise at work

With screwdriver according to the arrow direction compression planish, black mesh four black metal feet

14




注意事项:

In the case of no battery sound, you can external 5V DC power supply



3.5MM audio head can be an external audio equipment

Charge the special charger when inserted



Internal battery charging must use 4.2V dedicated charger, millions of access 5V power supply

[Instructions for use]

1. Switch machine:

OFF / ON power switch: false shutdown (uninterruptible case, only turn off the panel switch, will maintain low power consumption)

Power on: Turn the power switch to the "ON" position;

Shutdown: Set the power switch to the "OFF" position

2.MP3 playback:

Boot state to insert a copy of the MP3 song U disk or SD card, the machine will automatically identify and play, play MP3 button function as follows:

"On a song": short press to play on a song, long press the volume minus;

"Play / Pause": press the first pause is playing the song, press again to restore the playback state;

"Next song": short press to play the next song, long press the volume plus;

"MODE": machine work mode selection, switch SD card, U disk, clock, FM, Bluetooth, LINE mode;

3.FM mode:

Use the "MODE" key to switch the machine to the FM state. "Play / pause": short press to automatically search and store the radio; "next song": short press from low to high search for radio, Long press for volume plus.

4.LINE mode:

Press "MODE" on the panel to switch the machine to "LINE". The sound source is input from "LINE / DC", the volume is controlled by an external source device, and the volume can also be adjusted by "Previous" and "Next". The adjustment method is also the same as the MP3 volume adjustment.

5. Clock regulation:

Press "MODE" on the panel to switch to the "clock" state, press the "Play / Pause" button to select the time or minute, then select the part of the flash, then press "Previous" or "Next" adjustment time The (Note: after each boot to re-adjust the time)

6. Bluetooth mode:

Press the "MODE" on the panel to switch the machine to "BLUE" state, open the audio device with Bluetooth function, search for "ZTV-CT02EA" and connect it, the volume can be controlled by an external source device, One "and" next "to adjust the volume; phone call short press" play / pause "to answer the phone long press for the refusal.

When the call is on or the call is short, press "Play / Pause" to hang up.