


- Side-entry, 4-pin male JST SH-type connector.
- 3. To get the specified scale, select 100% in print settings. Drill location tolerance: ±0.1 [±5].
- 4. 5. Board edge tolerance: ±0.3 [±10].





User interface elements Scale 3:1

Side-entry, 4-pin male JST SH-type connector.

To get the specified scale, select 100% in print settings. Drill location tolerance: ±0.1 [±5]. 2.

3.

<u>/1.\</u>

4. Board edge tolerance: ±0.3 [±10].

