03WTE WIRE WRAP TOOL

- •Provides a modified wrap for 30 gauge kynar wire
- ·Strips, wraps and unwrap wire

Instructions For Stripping Insulation:

- 1. Press the wire to be stripped into the wire stripper's slot, about 1" from the end. (Fig. A) Pull the wire down into the slot.
- **2.** Push the wire stripper with the blade away from you to strip the insulation

Wrapping Wire:

- 1. Insert the stripped end of the wire into the tool's half moon-shaped hole on the edge of the tool and out through the groove in the tool. Insert until insulation bottoms out. (Fig.B)
- 2. Bend the wire over the tool and hold. (Fig.C)
- 3. Place the tool over the terminal or post and turn clockwise about 10 turns, to wrap the wire around the post. (Fig.D)

Unwrapping Wire:

- 1. To unwrap, place shortend of tool over post so wrapped wire seats in the end of the tool.
- 2. Turn tool counter-clockwise.





