## **GK-KIT-050 Instructions**

- 1. Attach 4 of the black M2x10mm screws and nuts to the corners of the base.
- 2. Remove the adhesive strip cover from the bottom of the battery holder.
- 3. Attach the battery holder centered with the long side aligned to the front edge of the base on the same side as the M2x10 screw heads.
- 4. Attach one bracket to each of the two vertical supports using two M2x10 screws and nuts with the screw heads on the bracket.
- 5. Attach the arm at the second hole from the end to the second hole down on the vertical supports with the M2x30mm chrome screw and nut.
- 6. Attach the complete arm and vertical support centered against the battery holder with 4 of the M2x12 black crews and nuts.
- 7. Twist the red and black wires from the battery holder and pass them through the seventh hole from the back of the arm.
- 8. Pass the red wire back through the arm in the opposite direction through the ninth hole from the back of the arm.
- 9. Insert the two LED wire connectors in opposite directions through first and second holes at the front of the arm.
- 10. Insert the LED into the two wire connectors in either direction.
- 11. Twist together the red wire from the battery pack to one of the wires from the LED.
- 12. Twist together the black wire from the battery pack to the other wire from the LED.
- 13. Insert two AA batteries into the holder.
- 14. Turn the switch on (to the front).
- 15. If the LED does not light reverse the LED in the connectors.
- 16. If the LED still does not light, make sure both twisted wires are making good contact.